


- ① - ESTABLISH CENTER BETWEEN RINGS BY LINING TAPE UP WITH THE CENTER ROOF JOIST OF THE ARENA.
- ② - OFFSET THE TAPE 1.5' EITHER SIDE OF CENTER LINE WITH STRING LINE TO ESTABLISH 3' CENTER AISLE.
- ③ - MEASURE 110' FROM WOODEN FENCE DOWN TO BOTTOM ALONG THE STRINGS LINES TO SET LOWER CORNERS.
- ④ - MEASURE THE 18' DIMENSION FROM LOWER WOODEN FENCE TO ESTABLISH THE DIRECTION OF THE 90'4" FENCE LINE TO SET NEXT CORNERS.
- ⑤ - MEASURE CLEARANCE FOR WARMUP JUMP ON RIGHT SIDE.
- ⑥ - MEASURE THE 105' DIMENSION ALONG THE CENTER ROOF RAFTER ALIGNMENT.
- ⑦ - ESTABLISH THE 75' DIMENSION FROM THE WOODEN FENCE DOWN, USING THE RING AND WARMUP JUMP CLEARANCE AS A GUIDE.
- ⑧ - SET THE 6' MINIMUM FOR FENCE CLEARANCES BOTH SIDES.
- ⑨ - MEASURE FROM THE INDICATED CORNERS TO ESTABLISH THE GATE LOCATIONS.



T. ED GARRISON ARENA
AGILITY COURSE FENCING LAYOUT
 NOT TO SCALE